

—BGH B3219H5  
—BGH B3219K5  
—BGH BL3201S  
—BGH BL3209S  
—BGH BL3210A  
—BGH BL3210D  
—BGH BL3211A  
—BGH BL3211D  
—BGH BL3277DSI  
—BGH BLE3212D  
—BGH BLE3213A  
—BGH BLE3213RT  
—BGH BLE3214D  
—BGH BLE3214DG  
—BGH BLE3214RT  
—BGH BLE3215D  
—BGH BLE3215RT  
—BGH BLE3216D  
—BGH BLE3216RT  
—BGH BLE3216RTXIPE BLE3216RTXIUY BLE3216RTXICL  
—BGH BLE3217RT BLE3217RTICL  
—BGH BLE3218RTX  
—BGH BLE3218RTXICL

—39

—BGH BLE3917RTF

—40

—BGH BLE4010D  
—BGH BLE4011D  
—BGH BLE4014D  
—BGH BLE4014DG  
—BGH BLE4014RT  
—BGH BLE4014RTX  
—BGH BLE4014RTX2  
—BGH BLE4015D  
—BGH BLE4015RT  
—BGH BLE4015RTFX  
—BGH BLE4016DF  
—BGH BLE4016RTF


—42




—BGH BL4209S  
—BGH BL4209X  
—BGH BL4210D  
—BGH BL4211D  
—BGH BLE4211D  
—BGH BLE4213RT  
—BGH BLE4213RTX

—43

—BGH B4318FH5  
—BGH B4319FK5  
—BGH BLE4316RTF  
—BGH BLE4317RTF  
—BGH BLE4317RTFICL  
—BGH BLE4318RTFXICL BLE4318RTFXIPE BLE4318RTFXIUY

—46





—HISENSE H32A5600  
—HISENSE HL3211A  
—HISENSE HLE3213A  
—HISENSE HLE3213RT  
—HISENSE HLE3214D  
—HISENSE HLE3214DG  
—HISENSE HLE3214RT  
—HISENSE HLE3215D  
—HISENSE HLE3216D  
—HISENSE HLE3216RT  
—HISENSE HLE3216RTXIPE HLE3216RTYIPE  
—HISENSE HLE3217RT HLE3217RTIPE

39  
—HISENSE HLE3917RTF

40  
—HISENSE HLE4011D  
—HISENSE HLE4011DX  
—HISENSE HLE4014RT  
—HISENSE HLE4014RTX  
—HISENSE HLE4014RTX2  
—HISENSE HLE4015DF  
—HISENSE HLE4015RTAI  
—HISENSE HLE4015RTFX  
—HISENSE HLE4016DF  
—HISENSE HLE4016RTF

42  
—HISENSE HLE4213RT  
—HISENSE HLE4213RTX


43  
—HISENSE 43A421GSV  
—HISENSE 43A42GSV  
—HISENSE H4318FH5  
—HISENSE H4319FK5  
—HISENSE HLE4316RTF  
—HISENSE HLE4317RTF  
—HISENSE HLE4317RTU


48  
—HISENSE HLE4815RT  
—HISENSE HLE4815RTFX

49  
—HISENSE H4918FH5 HLE4918RTFIPE  
—HISENSE HLE4916RTF  
—HISENSE HLE4917RTF HLE4917RTFIPE


50  
—HISENSE 50A64GSV  
—HISENSE H5018UH6  
—HISENSE H5018UH6IP  
—HISENSE HLE5015RTUX  
—HISENSE HLE5017RTU  
—HISENSE HLE5017RTUX  
—HISENSE HLE5017RTUXI  
—HISENSE HLE5017RTUXIPE

55  
—HISENSE 55A64GSV











—	JVC	LT32DA760	
—	JVC	LT32DA765	
—	JVC	LT32DA770	
—	JVC	LT32DA930	
—	JVC	LT32DA950	
—	JVC	LT32DR310	
—	JVC	LT32DR330	
—	JVC	LT32DR51	
—	JVC	LT32DR530	
—	JVC	LT32DR531	
—	JVC	LT32DR535	
—	JVC	LT32DR930	
39			
—	JVC	LT-39DA950	LT-39DA950M
—	JVC	LT39DA350	
—	JVC	LT39DA530	
—	JVC	LT39DR530	
40			
—	JVC	LT40DA560	
—	JVC	LT40DA570	
—	JVC	LT40DA760	
—	JVC	LT40DA770	
—	JVC	LT40DR710	
—	JVC	LT40DR730	
—	JVC	LT40DR750	
42			
—	JVC	LT-42R50	
—	JVC	LT42DA760	
—	JVC	LT42DA940	
—	JVC	LT42DA945	
—	JVC	LT42DA950	LT42DA950M
—	JVC	LT42DR530	
—	JVC	LT42DR531	
—	JVC	LT42DR532	
—	JVC	LT42DR935	
—	JVC	LT42DR940	
—	JVC	LT42DR945	
43			
—	JVC	LT43DA5125	
—	JVC	LT43DA760	
—	JVC	LT43DA770	
46			
—	JVC	LT46DR530	
—	JVC	LT46DR710	
—	JVC	LT46DR730	
—	JVC	LT46DR750	
—	JVC	LT46DR931	
—	JVC	LT46DR935	
47			
—	JVC	LT47DA940	
—	JVC	LT47DR940	
50			
—	JVC	LT-50KB66	
—	JVC	LT50DA7125	






- LG 42LB6200
- LG 42LB6500
- LG 42LD460
- LG 42LD650
- LG 42LD655
- LG 42LE4600-SA
- LG 42LF5850
- LG 42LG60FR
- LG 42LH20R
- LG 42LH30FR-MA
- LG 42LK450
- LG 42LK451
- LG 42LM3400
- LG 42LM5800
- LG 42LM6200
- LG 42LM6210
- LG 42LM6400
- LG 42LM6700
- LG 42LM7600
- LG 42LN5200
- LG 42LN5300
- LG 42LN5400
- LG 42LN5460
- LG 42LN5700
- LG 42LS3400
- LG 42LS5700
- LG 42LV3500
- LG 42LV3700
- LG 42LV5500


— 43

- LG 43LF5410
- LG 43LF5700
- LG 43LF5900
- LG 43LH5100
- LG 43LH5700
- LG 43LJ5500
- LG 43UF6400
- LG 43UH6500
- LG 43UJ6510
- LG 43UJ6560

— 47

- LG 47LA6130
- LG 47LA6200
- LG 47LA6600
- LG 47LA7400
- LG 47LB5800
- LG 47LB6500
- LG 47LD650
- LG 47LD655
- LG 47LK450
- LG 47LN5400
- LG 47LN5700
- LG 47LN5750
- LG 47LN5790











—	NOBLEX	42LC830FT	
—	NOBLEX	42LD844F	
—	NOBLEX	42LD850FI	
—	NOBLEX	42LD859FT	
—	NOBLEX	42LD862FI	
—	NOBLEX	42LD870FI	42LD870FIM
—	NOBLEX	42LD877FI	
43			
—	NOBLEX	43LD882FI	
—	NOBLEX	DI43X5100	DI43X5100X
—	NOBLEX	DI43X6500	
—	NOBLEX	DJ43X5100	
—	NOBLEX	DJ43X6500	
—	NOBLEX	DK43X5100	
—	NOBLEX	DM43X7100	
—	NOBLEX	EA43X5100	EA43X5100X
46			
—	NOBLEX	46LD825F	
—	NOBLEX	46LD836F	
—	NOBLEX	46LD845F	
—	NOBLEX	46LD852FI	
49			
—	NOBLEX	DI49X6500	
50			
—	NOBLEX	50LD863DI	
—	NOBLEX	50LD864FI	
—	NOBLEX	50LD865FO	
—	NOBLEX	50LD871DI	
—	NOBLEX	50LD876DI	
—	NOBLEX	50LD881DI	
—	NOBLEX	50LDAFADI	
—	NOBLEX	50LDUHDTI	50LDUHDTIN
—	NOBLEX	DA50X6500	DA50X6500X
—	NOBLEX	DE50X6500	
—	NOBLEX	DJ50X6100	
—	NOBLEX	DJ50X6500	
—	NOBLEX	DK50X6500	
—	NOBLEX	DM50X7500	
—	NOBLEX	DM50X7550	
—	NOBLEX	EA50X6100	EA50X6100X
—	NOBLEX	EA50X6500	
55			
—	NOBLEX	55LD856DI	
—	NOBLEX	55LD861DI	
—	NOBLEX	55LDUHDTI	55LDUHDTIN
—	NOBLEX	DA55X6500X	
—	NOBLEX	DI55X6500	
—	NOBLEX	DJ55X6500	
—	NOBLEX	DM55X7550	
—	NOBLEX	EA55X6500	
65			
—	NOBLEX	65LDUHDCU	65LDUHDCUN
—	NOBLEX	65LDUHDTI	
—	NOBLEX	DA65X6500	DA65X6500X





—PHILIPS 32PFG500077  
—PHILIPS 32PFG550977  
—PHILIPS 32PFL3007D77  
—PHILIPS 32PFL3008D77  
—PHILIPS 32PFL3017D77  
—PHILIPS 32PFL3018D77  
—PHILIPS 32PFL340377  
—PHILIPS 32PFL340477  
—PHILIPS 32PFL340577  
—PHILIPS 32PFL3406D77  
—PHILIPS 32PFL341477  
—PHILIPS 32PFL341577  
—PHILIPS 32PFL342577  
—PHILIPS 32PFL3518G77  
—PHILIPS 32PFL360577  
—PHILIPS 32PFL3606D77  
—PHILIPS 32PFL361577  
—PHILIPS 32PFL362577  
—PHILIPS 32PFL4007D77  
—PHILIPS 32PFL4017G77  
—PHILIPS 32PFL4508G77  
—PHILIPS 32PFL5007G77  
—PHILIPS 32PFL531277  
—PHILIPS 32PFL533277  
—PHILIPS 32PFL540377  
—PHILIPS 32PFL560477  
—PHILIPS 32PFL5605D77  
—PHILIPS 32PFL5606D77  
—PHILIPS 32PFL6605D77  
—PHILIPS 32PFL6606D77  
—PHILIPS 32PFL734277  
—PHILIPS 32PFL7606D78  
—PHILIPS 32PHG410977  
—PHILIPS 32PHG500077  
—PHILIPS 32PHG500177  
—PHILIPS 32PHG510077  
—PHILIPS 32PHG510177  
—PHILIPS 32PHG510277  
—PHILIPS 32PHG530177  
—PHILIPS 32PHG581377  
—PHILIPS 32PHG583377

37

—PHILIPS 37PFL533277  
—PHILIPS 37PFL731277

39

—PHILIPS 39PFG410977  
—PHILIPS 39PFL3508G77

40

—PHILIPS 40PFG500077  
—PHILIPS 40PFG510077  
—PHILIPS 40PFG550977  
—PHILIPS 40PFG611077  
—PHILIPS 40PFL5605D77  
—PHILIPS 40PFL5606D77

—PHILIPS 40PFL6605D77  
—PHILIPS 40PFL6606D77  
—PHILIPS 40PFL7606D77  
—PHILIPS 40PFL9605D78  
—PHILIPS 40PUG670077  
—PHILIPS 40PUG690977

42

—PHILIPS 42PFD470977  
—PHILIPS 42PFG501177  
—PHILIPS 42PFG651977  
—PHILIPS 42PFL3007D77  
—PHILIPS 42PFL3008D77  
—PHILIPS 42PFL340377  
—PHILIPS 42PFL3508G77  
—PHILIPS 42PFL360477  
—PHILIPS 42PFL360577  
—PHILIPS 42PFL361477  
—PHILIPS 42PFL361577  
—PHILIPS 42PFL362577  
—PHILIPS 42PFL4007G77  
—PHILIPS 42PFL4508G77  
—PHILIPS 42PFL4908G77  
—PHILIPS 42PFL5007G77  
—PHILIPS 42PFL5008G77  
—PHILIPS 42PFL533277  
—PHILIPS 42PFL540377  
—PHILIPS 42PFL543277  
—PHILIPS 42PFL560477  
—PHILIPS 42PFL6007G77  
—PHILIPS 42PFL7007G77  
—PHILIPS 42PFL731277  
—PHILIPS 42PFL734277  
—PHILIPS 42PFL740377  
—PHILIPS 42PFL780377  
—PHILIPS 42PFL8606D77  
—PHILIPS 42PFL990078

43

—PHILIPS 43PFD682577  
—PHILIPS 43PFD682577  
—PHILIPS 43PFG510177  
—PHILIPS 43PFG510277  
—PHILIPS 43PFG550177  
—PHILIPS 43PFG581377  
—PHILIPS 43PUG610277  
—PHILIPS 43PUG710077



46

—PHILIPS 46PFL4508G77  
—PHILIPS 46PFL6605D77  
—PHILIPS 46PFL7606D77

47


—PHILIPS 47PFG410977  
—PHILIPS 47PFG710977  
—PHILIPS 47PFL7007G77  
—PHILIPS 47PFL7008G77

	PHILIPS 47PFL740377
48	PHILIPS 48PFG500077
	PHILIPS 48PFG510077
	PHILIPS 48PFG550977
49	PHILIPS 49PFG510177
	PHILIPS 49PFG510277
	PHILIPS 49PFG550177
	PHILIPS 49PUG680177
	PHILIPS 49PUG710077
50	PHILIPS 50PFG410977
	PHILIPS 50PUD665477
	PHILIPS 50PUG610277
	PHILIPS 50PUG651377
	PHILIPS 50PUG660177
	PHILIPS 50PUG670077
	PHILIPS 50PUG690977
52	PHILIPS 52PFL543277
	PHILIPS 52PFL780377
	PHILIPS 52PFL8605D77
55	PHILIPS 55PFG730977
	PHILIPS 55PFL6007G77
	PHILIPS 55PFL8008G77
	PHILIPS 55PUD665477
	PHILIPS 55PUD679477
	PHILIPS 55PUG610277
	PHILIPS 55PUG621277
	PHILIPS 55PUG660177
	PHILIPS 55PUG670077
	PHILIPS 55PUG670377
	PHILIPS 55PUG680177
	PHILIPS 55PUG710077
58	PHILIPS 58PUD665477
65	PHILIPS 65PUD679477
	PHILIPS 65PUG641277
	PHILIPS 65PUG670377
	PHILIPS 65PUG680177
	PHILIPS 65PUG710077
70	PHILIPS 70PUG6774
75	PHILIPS 75PUD675477
PIONEER	
24	PIONEER PLE24HMN1
	PIONEER PLE24HMN2
32	PIONEER PLE32FMN2



—	RCA L32NSMART	
—	RCA L32NXSMART	
—	RCA L32NXSMARTFS	
—	RCA L32NXTSMART	
—	RCA L32S19SLIM	
—	RCA L32S80DIGI	
—	RCA L32S9500	
—	RCA L32S96DIGI	
—	RCA L32SKSMART	L32BKSMART
—	RCA L32T10SLIM	
—	RCA L32T20SMART	
—	RCA S32AND	
—	RCA XC32SM	
—	RCA XF32SM	
—	39	
—	RCA L39F50SLIM	
—	RCA L39NXSMART	
—	RCA L39NXSMARTFS	
—	RCA L39S85DIGI	L39S85DIGIFHD
—	RCA L39T10SLIM	
—	40	
—	RCA 40SMARTR30	
—	RCA AND40Y	
—	RCA L40NSMART	
—	RCA L40NXSMART	
—	RCA L40T20SMART	
—	RCA RC40P19S	
—	RCA S40AND	
—	RCA X40SM	
—	RCA XC40SM	
—	42	
—	RCA 42ISDB-T	
—	RCA AND42Y	
—	RCA L42F12USB	
—	RCA L42S19FHD	
—	RCA L42S96DIGI	
—	RCA XF42CH	
—	43	
—	RCA L43AND	
—	46	
—	RCA 46S88FHD	
—	RCA 46SMARTR30	
—	RCA L46E9FHD	
—	48	
—	RCA L48F50SLIM	
—	RCA L48NSMART	
—	RCA L48T10SLIM	
—	RCA L48T20SMART	
—	49	
—	RCA L49NXSMART	
—	RCA L49NXSMARTFS	
—	RCA L49NXTSMART	
—	RCA L49NXTSMARTFS	
—	50	





SAMSUNG UN32F4000AG  
SAMSUNG UN32F5000AG  
SAMSUNG UN32F5500AG  
SAMSUNG UN32F6300AF  
SAMSUNG UN32FH4005G  
SAMSUNG UN32H4303AG  
SAMSUNG UN32H5500AG  
SAMSUNG UN32H5550AG  
SAMSUNG UN32J4000AG  
SAMSUNG UN32J4300AG  
SAMSUNG UN32J5500AG

39

SAMSUNG UN39FH5005G

40

SAMSUNG LN40C550J1R  
SAMSUNG UN40D5003BG  
SAMSUNG UN40D5500RG  
SAMSUNG UN40EH5000G  
SAMSUNG UN40EH5300G  
SAMSUNG UN40EH6030G  
SAMSUNG UN40ES6100G  
SAMSUNG UN40ES6800G  
SAMSUNG UN40F5000AG  
SAMSUNG UN40F5500AG  
SAMSUNG UN40F6100AG  
SAMSUNG UN40F6300AF  
SAMSUNG UN40F6400AG  
SAMSUNG UN40F6800AG  
SAMSUNG UN40F7500AG  
SAMSUNG UN40FH5005G  
SAMSUNG UN40FH5303G  
SAMSUNG UN40H4200AG  
SAMSUNG UN40H4203AG  
SAMSUNG UN40H4203AH  
SAMSUNG UN40H5100AG  
SAMSUNG UN40H5103AG  
SAMSUNG UN40H5303AG  
SAMSUNG UN40H5500AG  
SAMSUNG UN40H6203AG  
SAMSUNG UN40H6400AG  
SAMSUNG UN40HU7000G  
SAMSUNG UN40HU7000K  
SAMSUNG UN40J5000AG  
SAMSUNG UN40J5200AG  
SAMSUNG UN40J5300AG  
SAMSUNG UN40J5500AG  
SAMSUNG UN40J6400AG  
SAMSUNG UN40JU6000G  
SAMSUNG UN40K5300AG  
SAMSUNG UN40K6500AG  
SAMSUNG UN40KU6000G  
SAMSUNG UN40KU6300G

43

SAMSUNG UN43KU6000G

46

SAMSUNG LN46D550K1F  
SAMSUNG LN46D550K1G  
SAMSUNG LN46D550K1M  
SAMSUNG LN46D550K1R  
SAMSUNG LN46D550K7G  
SAMSUNG LN46D610M4F  
SAMSUNG LN46D630M3F  
SAMSUNG UN46D5500RG  
SAMSUNG UN46D6900WG  
SAMSUNG UN46D7000LF  
SAMSUNG UN46D7000LG  
SAMSUNG UN46D7000LM  
SAMSUNG UN46D8000YG  
SAMSUNG UN46D8000YM  
SAMSUNG UN46D8000YR  
SAMSUNG UN46EH5000G  
SAMSUNG UN46EH5300G  
SAMSUNG UN46EH6030G  
SAMSUNG UN46ES6100G  
SAMSUNG UN46ES6800G  
SAMSUNG UN46ES7000G  
SAMSUNG UN46ES8000G  
SAMSUNG UN46F5000AG  
SAMSUNG UN46F5500AG  
SAMSUNG UN46F6100AG  
SAMSUNG UN46F6300AF  
SAMSUNG UN46F6400AG  
SAMSUNG UN46F6800AG  
SAMSUNG UN46F7500AG  
SAMSUNG UN46F8000AG  
SAMSUNG UN46FH5005G  
SAMSUNG UN46FH5303G  
SAMSUNG UN46H5303AG  
SAMSUNG UN46H6203AG

48

SAMSUNG UN48H4200AG  
SAMSUNG UN48H4203AG  
SAMSUNG UN48H5500AG  
SAMSUNG UN48H6300AG  
SAMSUNG UN48H6400AG  
SAMSUNG UN48H6800AG  
SAMSUNG UN48H8000AG  
SAMSUNG UN48J5300AG  
SAMSUNG UN48J5500AG  
SAMSUNG UN48J6400AG

49

SAMSUNG UN49K5300AG  
SAMSUNG UN49K6500AG  
SAMSUNG UN49KS7000G  
SAMSUNG UN49KS7500G  
SAMSUNG UN49KU6300G  
SAMSUNG UN49KU6400G  
SAMSUNG UN49KU6500G

50

SAMSUNG UN50EH5300G  
SAMSUNG UN50F5000AG  
SAMSUNG UN50F6300AF  
SAMSUNG UN50FH5303G  
SAMSUNG UN50H5303AG  
SAMSUNG UN50HU7000G  
SAMSUNG UN50J5300AG  
SAMSUNG UN50J5500AG  
SAMSUNG UN50KU6000G

55


SAMSUNG UN55D8000YG  
SAMSUNG UN55D8000YM  
SAMSUNG UN55D8000YR  
SAMSUNG UN55EH6030G  
SAMSUNG UN55ES7000G  
SAMSUNG UN55ES8000G  
SAMSUNG UN55F6100AG  
SAMSUNG UN55F6300AF  
SAMSUNG UN55F7500AG  
SAMSUNG UN55F8000AG  
SAMSUNG UN55H6103AG  
SAMSUNG UN55H6300AG  
SAMSUNG UN55H6800AG  
SAMSUNG UN55H7100AG  
SAMSUNG UN55H8000AG  
SAMSUNG UN55HU7000G  
SAMSUNG UN55HU7200G  
SAMSUNG UN55HU8500G  
SAMSUNG UN55J5300AG  
SAMSUNG UN55J5500AG  
SAMSUNG UN55J6400AG  
SAMSUNG UN55K5300AG  
SAMSUNG UN55K6500AG  
SAMSUNG UN55KS7000G  
SAMSUNG UN55KS7500G  
SAMSUNG UN55KS9000G  
SAMSUNG UN55KU6000G  
SAMSUNG UN55KU6300G  
SAMSUNG UN55KU6400G  
SAMSUNG UN55KU6500G

60


SAMSUNG UN60F6300AF  
SAMSUNG UN60H6103AG  
SAMSUNG UN60H6300AG  
SAMSUNG UN60H6400AG  
SAMSUNG UN60H7100AG  
SAMSUNG UN60KS7000G  
SAMSUNG UN60KU6000G

65

SAMSUNG UN65F6300AF  
SAMSUNG UN65F8000AG  
SAMSUNG UN65H6103AG  
SAMSUNG UN65H6400AG



	—	SANYO	LCE24XH15	
	—	SANYO	LCE24XH16	
	—	32		
	—	SANYO	LCD32XA2	
	—	SANYO	LCD32XF7	
	—	SANYO	LCD32XF8T	
	—	SANYO	LCD32XH3	
	—	SANYO	LCD32XH4	
	—	SANYO	LCD32XH6	
	—	SANYO	LCD32XH7	
	—	SANYO	LCD32XH8T	
	—	SANYO	LCD32XL2	
	—	SANYO	LCE32DH16	
	—	SANYO	LCE32DH17X	
	—	SANYO	LCE32ID17	LCE32ID17X
	—	SANYO	LCE32IH12	
	—	SANYO	LCE32IH13	
	—	SANYO	LCE32IH15	
	—	SANYO	LCE32IH16	
	—	SANYO	LCE32IH26	LCE32IH26X
	—	SANYO	LCE32IH51D	LCE32IH51DX
	—	SANYO	LCE32SH1000	
	—	SANYO	LCE32SH8200	
	—	SANYO	LCE32SH9500	
	—	SANYO	LCE32XF10	
	—	SANYO	LCE32XF9T	
	—	SANYO	LCE32XH10	
	—	SANYO	LCE32XH11	
	—	SANYO	LCE32XH12	LCE32XH12W
	—	SANYO	LCE32XH15	
	—	SANYO	LCE32XH16	LCE32XH16X
	—	SANYO	LCE32XH16DX	
	—	39		
	—	SANYO	LCE39IH12	LCE39IH12M
	—	SANYO	LCE39XF11	
	—	SANYO	LCE39XH12	
	—	40		
	—	SANYO	LCE40IF16	
	—	SANYO	LCE40IF26	LCE40IF26X
	—	SANYO	LCE40XF15	
	—	SANYO	LCE40XF16	LCE40XF16X
	—	SANYO	LCE40XF9T	
	—	42		
	—	SANYO	LCD42XF4	
	—	SANYO	LCD42XF6	LCD-42XF6B
	—	SANYO	LCD42XF7	
	—	SANYO	LCD42XF8T	
	—	SANYO	LCD42XH3	
	—	SANYO	LCD42XH4	
	—	SANYO	LCE42IF12	
	—	SANYO	LCE42IF13	
	—	SANYO	LCE42IF14	LCE42IF14M
	—	SANYO	LCE42IF15	
	—	SANYO	LCE42XF10	SANYO LCE42XF10B



- TCL L32S4900S
- TCL L32S6
- TCL L32S6500
- TCL LCD-32B330
- TCL LCD-32HDM61
- TCL LCD-32M100
- TCL LCD-32M150HD
- TCL LCD-32M95HD
- TCL LCD32M91HD
- TCL LED32B2600
- TCL LED32D3260D
- TCL LED32T3520

39

- TCL L39E5390
- TCL L39F3300DA
- TCL L39F3390
- TCL L39S4900
- TCL L39S4900S
- TCL LED39B2600

40

- TCL 40LEDM200
- TCL L40B2800
- TCL L40D2730A
- TCL L40S4900
- TCL L40S62
- TCL L40S6500
- TCL LCD40V8
- TCL LED40D3260FD

42

- TCL L42S6500
- TCL LCD-42HDM61
- TCL LCD-42M100
- TCL LCD-42M91FHD
- TCL LED42M400

43

46

- TCL 46LEDM200
- TCL L46E5390
- TCL LCD-46M91FHD
- TCL LED46M400

48

- TCL L48D2730A

49

- TCL L49S4900
- TCL L49S6
- TCL L49S62

50

- TCL L50B2800
- TCL L50P65
- TCL L50P715
- TCL L50P8M

55

- TCL 55LEDM200
- TCL L55C1



- TCL L55C2
- TCL L55E5500
- TCL L55E5800
- TCL L55H8800 CURVE
- TCL L55P4K
- TCL L55P4KSILVER
- TCL L55P6
- TCL L55P615
- TCL L55P65
- TCL L55P715
- TCL L55P8M
- TCL LCD-55P10FHD

65

- TCL L65C715
- TCL L65P4K
- TCL L65P6
- TCL L65P715
- TCL L65P8M

75

- TCL L75C2
- TCL L75P8M

TEEDGE

TELEFUNKEN

24

- TELEFUNKEN TKLE2413D
- TELEFUNKEN TKLE2414D
- TELEFUNKEN TKLE2415D
- TELEFUNKEN TKLE2416D

28

- TELEFUNKEN TKLE2814D

32

- TELEFUNKEN TKL3297S
- TELEFUNKEN TKL3297X
- TELEFUNKEN TKL3298A
- TELEFUNKEN TKL3299A
- TELEFUNKEN TKLE3213D
- TELEFUNKEN TKLE3214D
- TELEFUNKEN TKLE3215D
- TELEFUNKEN TKLE3216D
- TELEFUNKEN TKLE3218RTX
- TELEFUNKEN TKLE3219K5

43

- TELEFUNKEN TK4319FK5
- TELEFUNKEN TKLE4318RTFX

49

- TELEFUNKEN TKLE4918RTUX



50

- TELEFUNKEN TK5020UK6

TONOMAC

24

- TONOMAC TO-24-402-LED
- TONOMAC TO-24-4401-LED
- TONOMAC TO-24-4402-LED



55  
— TOP HOUSE KDL55XS712UN  
— TOP HOUSE KDL55XS718UN  
— TOP HOUSE KDL55XS782UN  
— TOP HOUSE UDL55MH547LN  
— TOP HOUSE UDL55MH794LN  
— TOP HOUSE UDL55XS788LN  
65  
— TOP HOUSE KDL65XS712UN